



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked  
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Electric Log Assembly	No longer available	4030-055	
1	240VAC Heater Assembly	No longer available	SRV4030-539EV	
2	Upper Glass Retainer	No longer available	4030-218	
3	Molded Ember Bed	No longer available	4030-913	
4	Rock Retainer	No longer available	4030-219	
5	Door Track	No longer available	4030-321	
6	Top Grille Assembly	No longer available	4030-090	
7	Black Louver Assembly	No longer available	4030-047	
8	Hood	No longer available	4030-530	
9	Screen & Rod Assembly	No longer available	4030-050	
10	Door Pivot Clip		SRV31527	
11	Light Tray Assembly	No longer available	SRV-020	
12	Flame Element Kit	No longer available	4030-200	
13	Halogen Light	Qty 2 req	33961	Y
14	Motor w/Vinyl Cover Assembly	No longer available	4030-883	
15	Acrylic Panel	No longer available	4038-810	
16	Lenticular Lens	No longer available	4030-840	
	Grate	No longer available	4030-896	
	Reflective Flame Decal	No longer available	4021-190	
	Installation Manual		4030-780	